WAX RECOMMENDATION



BOOK ACROSS THE BAY

Lake Superior, Ashland, WI - Saturday, Feb 15 6 P.M., 12k, Skate and Classic Wave start https://batb.org/race-information/course-conditions

<u>Forecast/Conditions:</u> Overnight low of 11, temperature at start will be 15 and dropping, snow will be fresh fallen and wind-blown. Expect the course to be variable but mostly cold wind-blown snow with Lake Superior ice mixed in.

Glidewax: Apply BP Blue Hot Wax, scrape and brush, then apply HP Blue Hot Wax, sprinkle on X-Cold Powder, iron in together, scrape and brush. Sprinkle on <u>Jet Powder</u> Blue, make two passes with iron at 18oc, let cool, scrape and brush. Polish with a merino wool roller. Then spray on <u>Jet Liquid</u> Blue, let the ski dry flat for at least 20 minutes. No need to brush or polish Jet Liquid before skiing.

<u>Gripwax:</u> Roughen base with 150 grit sandpaper, iron in Nordic Base Wax Green, cork smooth, let cool. Then apply 2-4 layers of Nordic GripWax Blue, corking smooth between layers.

<u>Structure</u>: A fine structure covered by one pass with the Blue Structurite tool after scraping and brushing the final Hot Wax or Jet Powder but before applying Jet Liquid will best suit these conditions.

Created by Blaise Sopiwnik, Toko Tech Team member since 2009

Racing-Service